Easy 5+

User Manual

Contents

1. Safety Precautions 2
2. Extra Safety Precautions 2
3. Introduction to This Phone 6
3.1 Keys 6
3.2 Display Screen 7
3.3 Status Icons 7
4. Instructins 7
4.1 Installation Instructions 7
How To Install the SIM Card 7
HSIM Card Codes/Password 7
PIN Code 8
SIM Card Precautions 8
4.2 Install the Battery and Battery Cover: 8
4.3 Charge/Recharge the Battery 8
4.4 Use of Battery 9
Monitoring Battery Power 9
Battery Power Reminder 9
4.5 Turn On or Off 9
4.6 Make a Call 10
International Call: 10
Dial an Extension Number 10
Dial a Short-cut Number 10
4.7 Adjust Volume 10
4.8 Answer a Call 11
4.9. Short-cut Numbers 11
4.10 SOS Function 11
4.11** Time Setting**: 12
4.12** Lock and Unkìlock Keys **..... 12
4.13 Hands free 17
5 Maintenance 12
5.1 Specification Parameters 13
5.2 Battery Information 13

1. Safety Precautions

Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

Safe driving

1)Do not use the phone when driving. When you have to use the phone, use only with the hands-free kit.

2) Place the phone safely in the phone stand. Do not put it onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

Turn off during a flight

Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

Turn off the phone when in the vicinity of areas with explosives or chemicals, flammable, dangerous or hazardous products

Be sure to strictly observe the related laws and statutes by turning off the phone when you are within, or in the vicinity of, an area where blasting takes place.

Please turn off your phone when you are within a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

Hospital and Medical Facilities

Please obey the related rules or bylaws of the hospital when using your phone in a hospital. Be sure to turn off your phone when near any medical equipment. Your use of any wireless transmission equipment, inclusive of the phone, will interfere with any medical equipment or other electronic equipment.

Interference

Each and every phone’s performance may be affected due to radio interference.

Professional service:

The phone must be installed or repaired by no other personnel than professionals. You are likely to suffer a huge risk when you install or repair this phone by yourself, which also goes against the warranty rules.

Fittings and battery

You shall use the fittings and battery acknowledged by the phone manufacturer only.

Proper use

Only use the phone as advised and described in this manual.

Avoid using the phone in areas that have cold or hot temperatures. Do not leave the phone exposed to direct sunlight or in areas very humid or

dusty.

Extreme care and attention to be taken before using the phone near medical devices such as but not only as pacemakers, hearing aids, or other electro-medical units that may be subject to interference from a mobile phone.

The various components and parts can cause choking if swallowed.

To avoid demagnetization, avoid keeping the Phone and accessories in the vicinity of magnetic substances such as, but not only, magnetic discs or credit cards.

Do not throw or put the phone or parts or accessories near fire.

Keep the phone at least 2,2cm away from your body.

Emergency call

You may enter a telephone number (112, etc.) to ask for emergency help after making sure that the phone has been turned on and is in the service status. Press the Send Key to call out, and report your position and introduce what has happened briefly. Do not end the call without authorization.

Note: Like any other phone, this phone's specific features may not be supported by some network whose coverage or wireless signaling is troubled (some network does not support calling for emergency service by 112. Therefore, do not rely wholly on this phone in case of some especial emergency (such as medical first aid, etc.). Please consult your local network operator for verification.

2. Extra Safety Precautions

The unit and the accessories can contain small parts. Keep them out of the reach of small children.

OPERATING ENVIRONMENT

Remember to follow any particular rules that may apply wherever you happen to be, and always turn off the unit whenever its use is forbidden, or it can cause interference or danger. Only use the units in its normal user position.

This unit complies with guidelines for radiation when it is used either in a normal position against your ear, or when it is at least 2.2 cm (7/8 inch) from your body. If the unit is carried close to your body in a case, belt holder or other holder, these should not contain any metal, and the product should be placed at the distance from yr body specified above. Make sure that the distance instructions above are followed until the transfer is complete.

Parts of the unit are magnetic, The unit can attract metal object. Do not keep credit cards or other magnetic media near the unit, as information stored on them can be erase.

MEDICAL UNITS

The use of equipment that transmits radio signals, e.g. mobile phones, can interfere with insufficiently protected medical apparatus. Consult a doctor or

the manufacturer of the apparatus to determine if it has adequate protection against external radio signals, or if you have any question. If notices have been put up at health care facilities instructing you to turn off the unit while you are there, you should comply. Hospitals and other health care facilities sometimes use equipment that can be sensitive to external radio signals.

PACEMAKER

Pacemaker manufacturers recommend a distance at least 15 cm. (6 inches) between a mobile phone and a pacemaker to avoid the risk of interference with the pacemaker. These recommendations are in accordance with independent research and recommendations from Wireless Technology Research. People with pacemakers should:

- always keep the unit at a distance of at least 15 cm from the pacemaker.
- not carry the unit in a breast pocket
- hold the unit against the ear on the opposite side from the pacemaker to reduce the risk of interference. If you suspect that there is a risk of interference, turn off the unit and move it further away.

HEARING AIDS

Some digital wireless units can cause interference to some hearing aids. Contact yr operator in case of interference.

VEHICLES

Radio signals can affect electronic systems in motor vehicles (e.g. electronic fuel injection, ABS brakes, automatic cruise control, air bag systems) that have been incorrectly installed or are inadequately protected. Contact the manufacturer or its representative for more information about yr vehicle or any additional equipment.

Do not keep or transport flammable liquid gases or explosives together with the unit or its accessories. For vehicles equipped with air bags: remember that air bags fill with air with considerable force.

Do not place objects, including fixed or portable radio equipment in the area above the airbag or the area where it might expand. Serious injuries may be caused if the mobile phone equipment is incorrectly installed and the airbag fills with air.

It is forbidden to use the unit whilst flying. Turn off the unit before you board a plane. Using wireless telecom units inside a plane can involve risk for air safety and interfere with telecommunications. It can also be illegal.

AREAS WITH EXPLOSION RISK

Always turn off the unit when you are in an area where there is a risk of explosion and follow all signs and instructions. An explosion risk exists in the places that include areas where your normally requested to turn off your car engine. Within such an area, sparks can cause explosion or fire which can lead to personal injuries, even death.

Turn off the unit at filling stations i.e. near petrol pumps and garages.

Follow the restrictions that are in force on the use of radio equipment near places where fuel is stored and sold, chemical factories and places where blasting is in progress.

Areas with risk for explosion are often – but not always – clearly marked.

This also applies to below decks on ships: the transport or storage of chemicals; vehicles that use liquid fuel (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powder.

EMERGENCY CALLS IMPORTANT!

Mobile phones such as this unit use radio signals, the mobile phone network, the terrestrial network and user-programmed functions. This means that connection in all circumstances cannot be guaranteed.

Therefore you should never rely solely on a mobile phone for very important calls such as medical emergencies.

SPECIFIC ABSOPTION RATE (SAR) CERTIFICATION INFORMATION (SAR)

This model meets international guidelines for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines.

These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons regardless of age and health.The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobile devices used by the general public is 2.0 W/kg. As SAR is measured utilising the device's highest transmitting power, the actual SAR of the device while operating is typically below the above indicated level. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level requested to reach the network. While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. The World Health Organization has stated that present scientific information does not indicate the need for any special precaution for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a "hands-free" device to keep the mobile phone away from the head and body.

WEEE REGULATIONS

The crossed-out wheeled bin means that within the European Union the product must be taken to separate collection at the products end-of-life. This applies to your device but also to any enhancements marked with this symbol. DO not dispose of these products as unsorted municipal waste.

3. Introduction to This Phone

Front View



1	**Up Button**	**6**	**Microphone**	**11**	**Charger Contact**
2	**Down Button**	**7**	**Light**	**12**	**SOS Button**
3	**OK Button**	**8**	**End Key**	**13**	**Charger /Earphone Socket**
4	**Earpiece**	**9**	**Send Key**		
5	**Keypad**	**10**	**Screen**		

3.1 Keys

This phone has the following keys:

Key	Name	Annotations
	Send Key	Press to Dial or answer a call.
	End Key	Press to end a call. Press for several seconds to turn the phone on or off. To cancel input of numbers to dial or to be saved.
	Up/ Down Key	Press in Edit mode to move the cursor. Press to adjust the volume during conversation.
	OK/Set Key	Press to save rapid dial phone numbers.
	Short-cut /Number Keys	Press key for rapid dialing phone numbers Press to digit numbers, and symbols supported.

	Signal Light	1) Red light flashing: battery is charging. 2) Green light : battery is full. 3) Green light flashing: connected to network. 4) No light: Not connected to network and/or SIM Card not valid.
	SOS	Press to dial SOS number.

3.2 Display Screen

When the phone is turned on the LCD screen shows:

1) On the left side the strength of the network signal
2) On the right side the battery power level.
3) The time.
2) Prompting text: instructions or messages.

3.3 Status Icons

Received signal strength: Battery power level:

4. Instructions

4.1 Installation Instructions

How To Install the SIM Card

THE PHONE MUST BE TURNED OFF AND DISCONNECTED FROM ANY DEVICE OR POWER SOURCE.

1)Turn the phone backside up and Gently press and push downwards the cover; preferably near the top of the phone, and gently remove.

2)Insert the SIM card, the seat is at the bottom on the left side, by very gently sliding the card into position .

Note: The cropped corner of the SIM card shall correspond to that of the outline of the seat and metal side downwards.

SIM Card Codes/Password

ATTENTION: To activate or deactivate this function the SIM Card must be inserted in a standard GSM phone as this phone does not have this function.

－PIN1 code

PIN code（Personal identify number）prevents unauthorized use of your phone. The **PIN** code usually comes from your service provider along with the **SIM** card.

If you enter the wrong code three times continuously, the **PIN** code is locked. To unlock the **PIN** code, you need a personal unlocking key (**PUK**) from your service provider.

—PIN2 code

Some functions, call costs for example, require a second **PIN2** code. The **PIN2** code comes from your service provider along with some of the SIM cards, and these functions are only available when the SIM card supports them.

If you enter the wrong PIN2 code three times, the **PIN2** code is locked. To unlock the PIN2 code, you need a personal unblocking key (**PUK2**) from your service provider.

PIN CODE

When the phone is turned on the message “Input PIN1 or PIN2 or PUK” appears.

1 Digit the correct Pin or PUK Code By pressing the number keys corresponding to the phone number to be dialed

Note : Press the keys In quick succession and once to input the first number , twice to input the second number and three times to input the third number

Example Pressing the "A" key Once inputs "1". Twice inputs "2". Three times inputs "3".

2. Press the Send Key to confirm

SIM Card Precautions:

1) Handle the SIM card with care, as scratches or bending damages the SIM card.

2) If the SIM card is inserted incorrectly or is invalid or damaged the screen will display “No SIM Card” after the phone is turned on. Remove the SIM card, check if it has been inserted correctly and re-insert correctly.

3）If the screen displays “SIM Card Damaged”, contact the network operator.

4.2 Install the Battery and Battery Cover:

1)After installing the SIM Card to install the battery .

2)The metal contacts on the battery must be facing the top and leftside.

3) Very gently position the battery contacts to the phone contacts and very gently push into place.

4)Replace the battery cover, by very gently placing the cover in position and gently slide to lock onto the back.

4.3 Charge/Recharge the Battery

1)The charger socket is on the right side of the phone below the SOS key.

2)Gently push the charger plug into the socket; **ensure the plug is in the correct position ; shape of the plug matches the shape of the socket.**

3)Connect the other end of the charger to the power source.

4)When battery is full, switch of the power source, remove the charger from the power source and the telephone

Note:

1) If the remaining power in the battery is too low to turn on the phone, charge the battery until full before turning on again the phone.

2) Make sure that the standard voltage and power are correct for the battery charger.

3) During the charging/recharging period, you may turn on or off the phone. But for better battery life it is best to have the phone turned off.

4) For safety it is best to never use the phone whilst connected to a power source and during charging.

4) Use the battery only for its intended purpose. Never use any charger or battery that is damaged or not original.

4.4 Use of Battery

Monitoring Battery Power

When the battery is low:

1) The battery low message displays.
2) The empty battery icon blinks.

Battery Power Reminder

1) If the battery is not in used for a long time, the same must be fully charged before use.
2) The battery can be charged and discharged many times, but it has a limited life time. When the conversation and standby times are noticeably shorter than usual, replace the battery.
3) If the battery is completely discharged, it takes a few minutes before the charging indicator appears on the display and needs to be charged for a few hours before the phone can be turned on
4) The battery is rechargeable and optimal performance of a new battery is only obtained after several complete charge and discharge cycles.
5) When a new battery is used for the first time or if the battery has not been used for a prolonged period, it is necessary to connect disconnect and reconnect a second time the charger to commence the charging of the battery.

4.5 Turn On or Off

1) Press the End key for a few seconds until the display lights up and the phone turns on. The screen shows the power-on display.
4) Press the End key for a few seconds until the turn of screen displays and the phone turns off.

To set the time on the display

1) On turning on the phone for the first time, of after removal of the battery for approximately 15 minutes or more, the time must be set.

2) Press the up/down key until the correct hours displays. Press the Send Key to confirm and the cursor automatically moves onto the minutes.

3) Press the up/down key until the correct minute displays. Press the OK key to confirm

3) The Phone automatically goes into standby.

4.6 Make a Call

After the SIM card, battery have been installed correctly and time has been set and phone has been turned on.

1) Press the number keys corresponding to the phone number to be dialed and then press the Send Key .

Note : Press the keys In quick succession and once to input the first number , twice to input the second number and three times to input the third number

Example Pressing the "A" key
Once inputs "1".
Twice inputs "2".
Three times inputs "3".

2) Press the End key to end the call.

International Call:

Press the key once, the screen shows a “+” symbol, which is the universal symbol for the international code. Enter the country code, area code and telephone number, and press the Send key to dial the number.

Dial an Extension Number

When the person to be dialed has the automatic extension number function.

After entering the phone number, press the key twice , the screen shows the letter “p” , enter the extension number, and press the Send key to dial the number.

Dial a Short-cut Number

Short-cut key:

1) Edit the speed dial numbers of **A, B, C, D, E** key in the indle screen.

2) Press the **A**, **B**, **C, D** or E key, then press the Send key to dial the number, or long press the **A**, **B**, **C, D** or E key to dial the number directly.

Note: Please refer to Short-cut Numbers for instructions on saving short-cut numbers .

4.7 Adjust Volume

During a call, yon can press the Up and Down button on the left side to adjust the volume louder or quieter.

4.8 Answer a Call

When the phone rings to answer the call:

1) Press the Send key
2) To end the call, press the End key
3) To refuse and not answer a call, press the End key

Note: If the caller ID can be identified, the phone will show the telephone number of the caller.

4.9 Short-cut Numbers

To insert and save a shortcut number

1) In the standby screen, press the OK key to enter the editing screen and “select the key” appears on the screen.
2) Press the key to which the number is to be saved, and displays on the screen.
   Example press the “A” key.
3) Press the OK key and “input number” appears on the screen
4) Insert the numbers of the phone number to be saved.
5) Press the OK key to save and “operate succeed” displays.

Note: Whilst inputting the numbers:

a) Press the up/down key to move the cursor backwards and forward

b) Press the end key to delete the number behind the cursor

c) Press the No. key once, twice in quick succession or three times in quick succession to input the corresponding number.

Example Pressing the "A" key once to input "1", twice quickly to input "2", three times quickly to input "3".

Save a short-cut from an incoming call.

The short-cut numbers can be saved from an incoming call when the number appears.

When the phone rings and the Phone number appears

1) Long press the shortcut-key to which the number is to be saved (A, B, C, D or E) until on the display “Replace?” appears.
2) Press the OK/key to save “number is saved” appears on the screen and the number is saved.

Note: Any number that was saved on the short-cut key is deleted and replaced by the new number.

4.10 SOS Function

This function allows the phone to automatically dial the short-cut numbers and not automatically dial emergency services.

The SOS button automatically dials the numbers registered in the shortcut keys In sequence. If the “A” key does not answer the phone sends an SMS with the word “Help” to this number and then dials the number in the “B” key and again if this number does

nsot answer it sends an SMS with the word "Help" and repeats the operation for all the shortcut keys (from A to E).

Note: IF the SIM card does not have credit or can not call out for any reason then the SOS button is not able to effect the procedure above.

1) Press for several seconds the SOS button to start an SOS call

The phone gives an alarm signal and on the display appears " Dial Emergency ? " after five seconds the call is dialled.

2) To make the call immediately and not after 5 seconds press the SOS key again.

3) Press the end key to cancel the call.

4,11 Time Setting

The time on the phone can be re-set by:

1) Press the E key twice until the "p" appears on the display.

2) Press the OK key and the time will appear on the screen.

3) Press the up/down key until the correct hours displays. Press the Send Key to confirm and the cursor automatically moves onto the minutes.

4) Press the up/down key until the correct minute displays. Press the OK key to confirm

5) The Phone automatically goes into standby.

4.12 Lock and Unlock keys.

Lock the Keys

1) Press the E key once so that the "+" symbol appears on the display.

2) Press the OK key and the keypad is locked, all the keys will not work. *In the top right hand corner of the display a key symbol appears.*

Note: the SOS key is still functional.

Unlock the Keys

1) Press the Ok key twice to unlock the keys.

4.13 Hands free

This option can only be activated during conversation.

To activate the hands free (loudspeaker) press the OK key.

To deactivate the hands free (loudspeaker) Press the OK key again.

5. Maintenance

※ Put the phone and all of its fittings in a place out of children's reach.

※ Keep the SIM card in good conditions. Do not bend or scraper it; be sure to avoid it from interference by static electricity. Use a piece of cloth that is static electricity proofing, and contains no chemical detergent, to clean the SIM card.

※ The phone shall be kept from moisture and shaking. Do not put it in

any place directly exposed to sunshine. Any liquid flowing into the phone will cause corrosion of the metal made electric circuit; and heat will shorten the service lives of the electronic component parts and damage the battery.

※ If the phone is not in use for a long time (more than one month), please take out the battery.

※ Phone ID: when you have lost your phone or SIM card, the following information is rather important, and shall be recorded: SIM card serial number (marked on the card); phone serial number (15-digit), and client number given by the network operator.

※ If you have lost your phone or SIM card, please contact your network operator immediately, to prevent any other person from using your phone illegally.

※ If the phone is not in use for a long time after being turned off, please separate the phone from its battery, so as to avoid the battery from suffering an electric leakage, and thus damaging the phone. If the battery is not in use for a long time (or has discharged its power), and cannot be charged normally by use of a traveler's charger, please use the charging stand to resume its charging performance.

5.1 Specification Parameters

Network Type: GSM850MHz/DCS1900MHz ;
GSM900MHz/DCS1800MHz
Dimensions: 87,47mm*54mm*212m (length*width*height)
Working Voltage: 3.7V-4.2V
Battery : BL888
Standby Time duration : 100-200 hours approximately
Maximum Call Time : 2-3 hours approximately

5.2 Battery Information

※ Do not throw the battery into fire.
※ Do not dismantle or retrofit the battery.
※ Do not put the battery into any unauthorized use.
※ Do not put the battery in any place in can be subject to mechanical solicitations in particular do not perforate the battery by use of any object.
※ The battery shall be kept in a cool and dry place, and away from high or low temperatures or exposure to direct sunshine.
※ Do not use the lithium battery in a cold environment as this reduces the battery's power and charge
※ Do not clean or bring the battery into contact with any liquid (example: water, solvent, oil).
※ Stop immediately use of the battery in case of odour of any kind or the phone and/or battery appear to be warmer than normal or a cool temperature.

※Stop immediately the use of the battery if it has any sign of alteration ; for example: cracked or cracks, shape is deformed or swollen, leakage or oxidation..

※ In case of contact of leakage with any surface, material or skin: rinse or wipe clean with soap and clean water immediately.

In case of contact with eyes: rinse immediately with clean water and contact qualified medical assistance immediately.

※ Use only original battery and charger, to avoid any damage or risks.

※ Always turn off the phone before and during handling the battery.

※ **Always dispose of the battery as per local regulations.**